



- NOTES:**
- 1 1/4" diameter holes in neoprene sheet must be drilled or punched so that neoprene sheet is not distorted at the time of installation.
 - For Td and Tc values see "TYPICAL CROSS SECTION" sheet for type I joint.

