



AC, PCC, RUBBER & OTHER BATCH OPERATIONS

Report Number calib district 109 by plant controller
 plant type date plant owner plant location

scale acceptable to useable scale capacity largest noted error, for this scale

scale number	step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
1	1	1000	0	1000	always zero for 1st step	1000	1000	0.0	0.0	Acceptable	
	2	2000	0	2000	0	2000	2000	0.0	0.0	Acceptable	
	3	3000	0	3000	0	3000	2990	-10.0	-1.0	Acceptable	
	4	4000	0	4000	0	4000	3990	-10.0	-1.0	Acceptable	
	5	5000	0	5000	0	5000	4990	-10.0	-1.0	Acceptable	
	6	6000	0	6000	0	6000	5990	-10.0	-1.0	Acceptable	

scale acceptable to useable scale capacity largest noted error, for this scale

scale number	step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
2	1	50	0	50	always zero for 1st step	50	51	1	1	Acceptable	
	2	100	0	100	0	100	101	1	1	Acceptable	
	3	200	0	200	0	200	201	1	1	Acceptable	
	4	300	0	300	0	300	301	1	1	Acceptable	
	5	400	0	400	0	400	401	1	1	Acceptable	
	6										

scale acceptable to useable scale capacity largest noted error, for this scale

scale number	step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
					always zero for 1st step						

scale acceptable to useable scale capacity largest noted error, for this scale

scale number	step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
					always zero for 1st step						

Test Notes
 Plant Certified for State Use
 Interlocks O.K.
 Printer O.K.