

882

SEAT BELT TESTS  
TYPE 2 SEAT BELT ASSEMBLY  
NON-LOCKING RETRACTOR  
by Merle Wilson

72-56

DND



5882

1

Test Authorization Date: May 21, 1971

Report Date: April 6, 1972

Test Report No. 1151

Name of Device: REPA No. 01.90211.1  
Type 2 Seat Belt Assembly.  
Non-locking Retractor.

Submitted by: California Highway Patrol

SUMMARY OF TEST

Seat Belt Tests: See Data Sheets for Individual Tests

This is a Standards Conformity Evaluation Report.

This report contains the results of tests performed to determine compliance with the applicable requirements of Federal Vehicle Safety Standard No. 209.

JOHN L. BEATON  
Materials and Research Engineer

By Merle E. Wilson

520

RECEIVED  
JAN 10 1964  
FBI  
BOSTON  
MASS

Test No. 1151

Name of Device: Volkswagen-Repa No. 01-90211.1  
Type 2 Seat Belt Assembly  
Non-locking Retractor.

NOTES: FOR CHP ONLY

These belts failed to meet the requirements of the following sections:

- S4.1 Requirements for Complete Assembly
  - (L) Installation instructions not supplied.
  - (M) Usage and maintenance instructions not supplied.
- S4.3 Requirements for Hardware
  - (c)2 Attachment hardware designed to receive the ends of two seat belt assemblies - All three devices failed as noted in Note 3, Page 18. These may or may not be considered as failures.

Report Fee: \$ 540.00 plus overhead assessment of 8.39%.





TESTS AND INSPECTION

<u>FM VSS Section Number</u>	<u>Specifications</u>	<u>Results of Test and Inspection</u>
S4.	Requirements for complete assembly.	
S4.1 (a)	Single occupancy	<u>Satisfactory</u>
(b)	Pelvic restraint	<u>Satisfactory</u>
(c)	Upper torso restraint	<u>Satisfactory</u>
(d)	Hardware - Free from burrs and sharp edges	<u>Satisfactory</u>
(e)	Release Type 1 or 2 - Accessible for easy and rapid release Type 3 - Readily accessible to an adult for easy and rapid release	<u>Satisfactory</u>
(f)	Attachment hardware - Includes all hardware for installation in accordance with SAE J800b	<u>Satisfactory</u>
(g)	Adjustment - Capable of snug adjustment	<u>Satisfactory</u>
(h)	Seat back retainer - Retainer is included for Type 3 belts used on hinged seats.	<u>N/A</u>
(i)	Webbing - Ends are protected or treated to prevent raveling and cannot pull out of adjustment hardware	<u>Satisfactory</u>
(j)	Strap - Meets requirements of S4.2, S4.3 and S4.4 if applicable.	<u>N/A</u>
(k)	Marking - permanently and legibly marked or labeled with year of manufacture, model and name or trademark of manufacturer.	<u>Satisfactory</u>
(l)	Installation instructions - Shall include applicable items in SAE J800b	<u>None supplied</u>
(m)	Usage and maintenance instructions	<u>None supplied</u>
(n)	Workmanship	<u>Satisfactory</u>





Name of Device: Volkswagen - Repa No. 01.90211.1 Type 2 Seat Belt Assembly. Non-Locking Retractor.

Devices Received: Nine devices, May 21, 1972

Description: Refer to photographs.

Buckle: Frame- duplex 0.101" steel straps, in angular shape to conform to drive shaft tunnel and 0.102" flat steel strap. The assembly receives either or both driver's or passenger's seat belts. Black plastic cover. Latch - 0.193" steel wire, bent and inserted into the locking dog, with nylon housing and wire spring.

Locking Dog- 0.552" x 0.88" steel rod.

Tongue: Frame and tongue - 0.100" stamped steel with black plastic cover.

Sliding webbing grip - 0.158" stamped steel, looped for pelvic and upper torso webbing and includes a spring loaded bar to allow length adjustments.

Webbing:

Weave - Twill  
Material - Nylon  
Color - Black  
Stitching- Modified "W"

Maximum Length:  
Pelvic Belt - 61" overall  
Shoulder Belt - 51"

Mounting Hardware: Bracket Inboard Side - See Buckle-Frame above.  
Bracket Outboard Side Lap Bolt-0.121" stamped steel.  
Bracket Outboard Side Shoulder Belt - 0.121" stamped steel  
Bolts (2) Outboard Side - Steel 7/16"-20x1" with 1/4" shoulder.  
Bolts (2) Inboard Side, Duplex Buckle - steel 7/16"-20 x 3/4" without shoulder



Name of Device: Volkswagen-Repa No. 01.90211.1 (continued)

Marks of Identification:

Printed on a 1-3/8" by 2 1/4" cloth label sewn to shoulder belt webbing:

"VW"	Trademark in 1/4" diameter circle.
"113 857 721A"	In 1/8" numerals and letter.
"REPA 01.90211.1"	In 1/8" letters and numerals.
"MVS STD 209"	In 1/8" letters and numerals.
"1970"	In 1/8" numerals.
"MADE IN GERMANY"	In 1/16" letters.

Stamped on Tongue

"REPA"	In 3/32" letters.
"01.00076.0"	In 3/32" numerals.
"1970"	In 3/32" numerals.

Stamped on Black Plastic Trim Cover of Tongue:

"VW"	Trademark in 15/32" diameter circle.
"REPA 01.00087.0"	In 3/32" letters and numerals.

Stamped on the drivers side inboard attachment bracket:

"REPA"	In 3/32" letters.
"01.0033.0"	In 3/32" numerals.
"1970"	In 3/32" numerals.

Stamped on the passengers side inboard attachment bracket:


"REPA"	In 3/32" letters.
"01.0034.0"	In 3/32" numerals.
"1970"	In 3/32" numerals.

Stamped on each half of the Black Plastic Trim Cover of the Buckle:

"VW"	Trademark in 5/8" diameter circle.
"311 857 753"	In 3/32" numerals.
"REPA 01.9003.0"	In 3/32" letters and numerals.

Stamped on each of the outboard attachment brackets, Lap Belt Side and Shoulder Belt Side:

"REPA 01.00280"	In 1/16" letters and numerals
"VW"	Trademark in 3/16" diameter circle.
"111 857 775A"	In 1/16" numerals and letter.



Name of Device: VOLKSWAGEN- REPA NO.01.90211.1

Marks of Identification: (continued)

Raised on white plastic retractor spring housing:

"SPANNEN DURCH 8-MALIGE UMDREHUNG" In 1/8" and 1/16" upper and lower case letters

"WIND SIX TO EIGHT TIMES" In 1/8" and 1/16" upper and lower case letters.

Raised on white plastic webbing retainer of retractor housing:


"MADE IN GERMANY" In 1/16" letters

"GHE" Trademark in 1/16" letters.

Raised on the top of all bolts:

"REPA" In 3/32" letters  
" " In 3/32" high figure  
"8.8" In 3/32" numerals









## Photographs

Name of Device: VOLKSWAGEN-REPA No. 01.90211.1  
Type 2 Seat Belt Assembly - Non-locking Retractor.





VW  
113 837 721A  
9096 01.90211.1  
MKS 510-208  
1210  
MADE IN GERMANY



Test No. 1151

## Photographs (continued)

Name of Device: VOLKSWAGEN-REPA No. 01.90211.1.



W. J. J.

8341

8

Requirements for Webbing

S4.2

- (a) Width - shall not be less than 1.8 inches for Type 1 or 2 and 0.9 inches for Type 3. \* See Note 1, Page 18.

<u>Belt No.</u>	<u>Location</u>	<u>Width (Inches)</u>	
B- 1	Pelvic	2.05	
	Upper Torso	N/A	*
B- 2	Pelvic	2.00	
	Upper Torso	N/A	*
B- 3	Pelvic	2.05	
	Upper Torso	N/A	*

- (b) Breaking Strength

Type 1 - Min. 6000 lbs.

<u>Belt No.</u>	<u>Breaking Strength (Lbs)</u>	
B- N/A		
B- N/A		
B- N/A		Median N/A

Type 2 - Pelvic - Min. 5000 lbs. (Except that a pelvic restraint of a Type 2 seat belt assembly that can be used without the upper torso restraint shall have a minimum of 6000 lbs.)

<u>Belt No.</u>	<u>Breaking Strength (Lbs.)</u>	
B- 1	5,301	
B- 2	5,550	
B- 3	5,600	Median 5,550

Type 2 - Upper Torso - Min. 4000 lbs. See Note 1, Page 18.

<u>Belt No.</u>	<u>Breaking Strength (Lbs.)</u>	
B- N/A		
B- N/A		
B- N/A		Median N/A

0052 19 404 . . .

204

1. 4  
1. 4  
1. 4



(c) Elongation

Type 1 - Max. 20% at 2500 lbs.

<u>Belt No.</u>	<u>Elongation (%)</u>
B- <u>N/A</u>	<u>          </u>
B- <u>N/A</u>	<u>          </u>
B- <u>N/A</u>	<u>          </u>

Type 2 - Pelvic - Max. 30% at 2500 lbs. (Except that a pelvic restraint of a Type 2 seat belt assembly that can be used without the upper torso restraint shall have a maximum of 20% at 2500 lbs.)

<u>Belt No.</u>	<u>Elongation (%)</u>
B- <u>1</u>	<u>21.5</u>
B- <u>2</u>	<u>20.5</u>
B- <u>3</u>	<u>20.0</u>

Type 2 - Upper Torso - Max. 40% at 2500 lbs.

<u>Belt No.</u>	<u>Elongation (%)</u>	See Note 1, Page 18.
B- <u>N/A</u>	<u>          </u>	
B- <u>N/A</u>	<u>          </u>	
B- <u>N/A</u>	<u>          </u>	

## (d) Resistance to Abrasion - Minimum breaking strength after abrasion test shall be at least 75% of original strength.

<u>Pelvic</u>	<u>Belt No.</u>	<u>Breaking Strength (Lbs.)</u>	<u>% of Original</u>
B-	<u>1</u>	<u>5,160</u>	<u>97.3</u>
B-	<u>2</u>	<u>5,100</u>	<u>91.9</u>
B-	<u>3</u>	<u>5,000</u>	<u>89.3</u>
Median		<u>5,100</u>	Median <u>91.9</u>

10

11

08

8

8.1.1

Upper Torso See Note 1, Page 18.

Belt No.	Breaking Strength (lbs)	% of Original
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
Median <u>N/A</u>		Median <u>N/A</u>

- (e) Resistance to Light - Minimum breaking strength after light test shall be not less than 60% of original strength. See Note 2, Page 18.

Pelvic	Belt No.	Breaking Strength (lbs)	% of Original
	B- <u>                    </u>	<u>                    </u>	<u>                    </u>
	B- <u>                    </u>	<u>                    </u>	<u>                    </u>
	B- <u>                    </u>	<u>                    </u>	<u>                    </u>
	Median <u>                    </u>		Median <u>                    </u>

<u>Upper Torso</u>		See Note 1, Page 18.	
<u>Belt No.</u>	<u>(lbs)</u>	<u>Breaking Strength</u>	
		<u>% of Original</u>	
<u>N/A</u>	<u>                    </u>	<u>                    </u>	
<u>N/A</u>	<u>                    </u>	<u>                    </u>	
<u>N/A</u>	<u>                    </u>	<u>                    </u>	
<u>Median</u>	<u>N/A</u>	<u>Median</u>	<u>N/A</u>

125

125

Requirements for Hardware

S4.3

(a) Corrosion Resistance

(1) Attachment hardware (including retractors)

<u>Belt No.</u>	<u>Results</u>
B- <u>1</u>	<u>Satisfactory</u> _____ _____
B- <u>2</u>	<u>Satisfactory</u> _____ _____
B- <u>3</u>	<u>Satisfactory</u> _____ _____

(2) Buckles and metallic parts other than attachment hardware.

<u>Belt No.</u>	<u>Results</u>
B- <u>4</u>	<u>Satisfactory</u> _____ _____
B- <u>5</u>	<u>Satisfactory</u> _____ _____
B- <u>6</u>	<u>Satisfactory</u> _____ _____

33



(b) Temperature Resistance

<u>Belt No.</u>	<u>Results</u>
B- <u>1151-4</u>	<u>Satisfactory</u>
B- <u>1151-5</u>	<u>Satisfactory</u>
B- <u>1151-6</u>	<u>Satisfactory</u>

(c) Attachment Hardware

1. Eye bolts, shoulder bolts and other bolts shall withstand 9000 lbs, or 5000 lbs if single belt only.

<u>Belt No.</u>	<u>Location</u>	<u>Load (lbs.)</u>	<u>Failure</u>
B- <u>4</u>	Inboard	<u>9020</u>	<u>None</u>
	Outboard	<u>5100</u>	<u>None</u>
B- <u>5</u>	Inboard	<u>9010</u>	<u>None</u>
	Outboard	<u>5010</u>	<u>None</u>
B- <u>6</u>	Inboard	<u>9050</u>	<u>None</u>
	Outboard	<u>5030</u>	<u>None</u>

2. Other attachment hardware designed to receive the ends of two seat belt assemblies shall withstand 6000 lbs.

<u>Belt No.</u>	<u>Load (lbs.)</u>	<u>Failure</u>	
B- <u>4</u>	<u>5790</u>	<u>Failed</u>	See Note 3, Page 18.
B- <u>5</u>	<u>6010</u>	<u>Failed</u>	See Note 3, Page 18.
B- <u>6</u>	<u>6200</u>	<u>Failed</u>	See Note 3, Page 18

3. Quick disconnect hooks retaining latch shall not move more than 0.80 inches in vertical or horizontal direction when loaded to 150 lbs.

<u>Belt No.</u>	<u>Location</u>	<u>Vertical Movement (Inches)</u>	<u>Horizontal Movement (Inches)</u>
B- <u>N/A</u>	Pelvic		
	Upper Torso		
B- <u>N/A</u>	Pelvic		
	Upper Torso		

2 10 11

- (1) Type 1 and Type 2 - 30 lbs. max.

<u>Belt No.</u>	<u>Location</u>	<u>Force (lbs)</u>
B- <u>4</u>	Pelvic	<u>11.0</u>
	Upper Torso	<u>6.5</u>
B- <u>5</u>	Pelvic	<u>9.0</u>
	Upper Torso	<u>5.0</u>
B- <u>6</u>	Pelvic	<u>11.0</u>
	Upper Torso	<u>13.0</u>

**Type 3 - 20 lbs. Max.**

<u>Belt No.</u>	<u>Force (lbs.)</u>
B- <u>N/A</u>	
B- <u>N/A</u>	
B- <u>N/A</u>	

- (2) Pushbutton Area - 0.7 sq. inches and 0.4 inches min. linear dimension,

Area N/A sq.in.

Lever type shall permit insertion of .4 inch by 1.5 inch long bar. Satisfactory

- (3) Pushbutton shall not release under 400 lbs. compressive load.

<u>Belt No.</u>	<u>Results</u>
B- <u>N/A</u>	
B- <u>N/A</u>	
B- <u>N/A</u>	



## (e) Adjustment Force - 11 lbs. max.

<u>Belt No.</u>	<u>Location</u>	<u>Adjustment Force (lbs.)</u>
B- <u>4</u>	Pelvic	<u>6.0</u>
	Upper Torso	<u>7.0</u>
B- <u>5</u>	Pelvic	<u>8.0</u>
	Upper Torso	<u>8.5</u>
B- <u>6</u>	Pelvic	<u>7.0</u>
	Upper Torso	<u>6.5</u>

## (f) Tilt-Lock Adjustment - 30° min.

<u>Belt No.</u>	<u>Location</u>	<u>Locking Angle (Degrees)</u>
B- <u>4</u>	Pelvic	<u>48</u>
	Upper Torso	<u>44</u>
B- <u>5</u>	Pelvic	<u>39</u>
	Upper Torso	<u>59</u>
B- <u>6</u>	Pelvic	<u>40</u>
	Upper Torso	<u>37</u>

(g) Buckle latch

Buckle latch cycling - Normal latching and unlatching shall not be impaired. If partial engagement is possible - Separation force - 5 lbs. Max.

<u>Belt No.</u>	<u>Belt Component</u>	<u>Separation Force (lbs.)</u>	<u>Results Cycling Tests</u>
B- <u>4</u>	Pelvic	<u>Partial engagement</u>	<u>Satisfactory</u>
	Upper Torso	<u>not possible</u>	
B- <u>5</u>	Pelvic	<u>Partial engagement</u>	<u>Satisfactory</u>
	Upper Torso	<u>not possible</u>	
B- <u>6</u>	Pelvic	<u>Partial engagement</u>	<u>Satisfactory</u>
	Upper Torso	<u>not possible.</u>	

(h) Non-locking retractor

Pelvic restraint, residual extension of web - 0.25" max.

<u>Belt No.</u>	<u>Extension (Inches)</u>
B- <u>7</u>	<u>0.05</u>
B- <u>8</u>	<u>0.10</u>
B- <u>9</u>	<u>0.10</u>





Upper torso restraint, maximum retraction force - 1.1 lbs.

<u>Belt No.</u>	<u>Retraction Force (lbs.)</u>
B- <u>N/A</u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>

(i) Automatic - locking retractor

Retraction force

Pelvic - 0.60 lbs. min.  
Upper Torso - 0.45 lbs. min.  
Belt movement between locking dogs  
Both belt types - 1 inch max.

<u>Belt No.</u>	<u>Belt Component</u>	<u>Retractor Force (lbs.)</u>	<u>Movement Inches)</u>
B- <u>N/A</u>	Pelvic	<u>                    </u>	<u>                    </u>
	Upper Torso	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	Pelvic	<u>                    </u>	<u>                    </u>
	Upper Torso	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	Pelvic	<u>                    </u>	<u>                    </u>
	Upper Torso	<u>                    </u>	<u>                    </u>

(j) Emergency locking retractor

Pelvic retractor - max. extension under 0.5 g load is 1 inch  
retractor force - 1.5 lbs. min.

<u>Belt No.</u>	<u>Extension (Inches)</u>	<u>Retraction Force (lbs.)</u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>



Upper torso retractor - max. extension under 0.5 g load is 1 inch; retraction force - 0.45 lbs. min., 1.1 lb. max.

<u>Belt No.</u>	<u>Extension (Inches)</u>	<u>Retraction Force (lbs)</u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>

(k) Performance of retractor

Final retraction force shall not be less than 50% of its original value

<u>Belt No.</u>	<u>Original Force (lbs)</u>	<u>Final Force (lbs)</u>	<u>% of Original</u>
B- <u>7</u>	<u>0.41</u>	<u>0.24</u>	<u>59</u>
B- <u>8</u>	<u>0.41</u>	<u>0.25</u>	<u>61</u>
B- <u>9</u>	<u>0.44</u>	<u>0.22</u>	<u>50</u>

S4.4

Requirements for Assembly Performance

(a) Type 1 Seat Belt

- (1) The assembly loop shall withstand a force of not less than 5000 lbs.
- (2) The length of the pelvic restraint between anchorages shall not increase more than 14 inches when loaded to 5000 lbs (7 inches loop extension).
- (3) Any webbing cut by the hardware during the test shall have a breaking strength at the cut of not less than 4,200 lbs.
- (4) Complete fracture through any solid section of metal attachment hardware shall not occur during test.

<u>Belt No.</u>	<u>Loop Load (lbs)</u>	<u>Assembly Extension (Inches)</u>	<u>Webbing Cut</u>	<u>Webbing Retest</u>	<u>Hardware Failures</u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>
B- <u>N/A</u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>	<u>                    </u>



(b) Type 2 Seat Belt

- (1) The structural components in the pelvic restraint shall withstand a force of not less than 2500 lbs. (Except that a pelvic restraint of a Type 2 seat belt assembly that can be used without upper torso restraint shall comply with requirements for Type 1 seat belt assembly).
- (2) The structural components in the upper torso restraint shall withstand a force of not less than 1500 lbs.
- (3) The structural components that are common to pelvic and upper torso restraints shall withstand a force of not less than 3000 lbs.
- (4) The length of the pelvic restraint between anchorages shall not increase more than 20 inches when loaded to 2500 lbs.
- (5) The length of the upper torso restraint between anchorages shall not increase more than 20 inches when loaded to 1500 lbs (10 inches loop extension).
- (6) Webbing cut by the hardware during test shall have a breaking strength of not less than 3500 lbs for webbing in the pelvic restraint or not less than 2800 lbs for webbing in the upper torso restraint.
- (7) Complete fracture through any solid section of metal attachment hardware shall not occur during test.

<u>Belt No.</u>	<u>Belt Component</u>	<u>Loop Load (lbs.)</u>	<u>Assembly Extension Inches</u>	<u>Webbing Cut</u>	<u>Webbing Retest</u>	<u>Hdwe. Failure</u>
B- <u>4</u>	Pelvic	<u>5000</u>	<u>9.0</u>	<u>None</u>	<u>N/A</u>	See Note 3, Page
	Upper Torso	<u>1500</u>	<u>4.0</u>	<u>None</u>	<u>N/A</u>	None
	Common	<u>3100</u>	<u>8.25</u>	<u>None</u>	<u>N/A</u>	None
B- <u>5</u>	Pelvic	<u>5010</u>	<u>8.75</u>	<u>None</u>	<u>N/A</u>	See Note 3, Page 1
	Upper Torso	<u>1500</u>	<u>5.0</u>	<u>None</u>	<u>N/A</u>	None
	Common	<u>3300</u>	<u>8.0</u>	<u>None</u>	<u>N/A</u>	None
B- <u>6</u>	Pelvic	<u>5020</u>	<u>9.0</u>	<u>None</u>	<u>N/A</u>	See Note 3, Page
	Upper Torso	<u>1530</u>	<u>5.5</u>	<u>None</u>	<u>N/A</u>	None
	Common	<u>3050</u>	<u>7.75</u>	<u>None</u>	<u>N/A</u>	None

ClibPDF - [www.fastio.com](http://www.fastio.com)

Name of Device: VOLKSWAGEN-REPA No. 01.90211.1 Type 2 Seat Belt Assembly. Non-locking Retractor.

NOTES:

1. Webbing for the pelvic portion and the upper torso portion are common, therefore only the pelvic portion was tested, Pages 8,9, 10.
2. There was insufficient length of webbing to perform the Resistance to Light Breaking Strength, (Page 10); therefore, webbing taken from Devices B-7,8, and 9 was used and compared to the median value of the original breaking strengths from Devices B-1, 2, and 3, (Page 8.)
3. During the testing of the attachment hardware designed to receive the ends of two assemblies; S4.3(c)2, page 12; the test was attempted during the assembly performance and the tongue pulled out at a load of 5790 lbs on Device B-4. Subsequent testing of Devices B-5 and B-6 under this section was performed by placing two tongues in the duplex buckle and pulling the 6000 lbs. load through the webbing attached to the tongues. It is also noted that the 0.230" x 7/16" long machine screws on each of the three devices B-4, B-5, and B-6 failed at loads of 3500 lbs, 3800 lbs, and 3360 lbs, respectively. See photos, Page 7.



