

large scoop) to transport the polymer concrete from the mixer to the rigid test frame.

2. Use the wooden block to strike off the fresh polymer concrete. Place the block on top of the test area, with its 85-mm width touching the polymer concrete surface and its ends extending beyond the rigid frame. Strike the top of the block with the mallet at various locations. Move the block, and restrike as needed, to achieve uniform consolidation throughout the test area. The rigid frame must remain in full contact with the surface to be overlaid during the consolidation process. After consolidation, flushed resin should be evenly distributed throughout the surface of the polymer concrete.
3. Remove the wooden block from the test area and place a sheet of polyethylene on top of the polymer concrete. Gently place the nuclear gage on top of the plastic sheet at the center of the test area. Take a 1-min reading with the nuclear gage in the AC Backscatter Mode. Turn the nuclear gage 180 degrees and obtain an additional 1-min reading. Average the two readings. Calculate the count ratio by dividing the count value by the average of the two readings. Use the calibration chart for the nuclear gage to determine the in-place density. See California Test 231. This obtained value represents the standard compacted density for one day's use. If there is a significant change in the resin content, the depth of the overlay, the aggregate source or gradation, a new standard density must be determined.
4. For a valid test, the following items must be completed within a 7-min period: sampling the polymer concrete, filling the rigid frame with material, compacting the polymer concrete, and obtaining the nuclear gage readings.

NOTE 1:

Immediately after all nuclear gage readings are recorded, quickly clean the rigid test frame and all equipment with cleaning solvent before

the polymer concrete gels. Properly dispose of all polymer concrete materials used in the compaction test.

E. IN-PLACE DENSITY TEST

1. The relative compaction test must be taken immediately after the polymer concrete has been placed and finished, and before any surface sanding or texturing. Place a sheet of polyethylene on the polymer concrete surface and gently place the nuclear gage on the polyethylene sheet. Take a 1-min reading with the nuclear gage in the AC Backscatter Mode. Calculate the in-place density and the relative compaction of the material at the site. The formula to calculate percent relative compaction is:

$$\frac{(\text{In-Place Density})}{(\text{Standard Density})} \times 100 = \% \text{ Relative Compaction}$$

2. The % relative compaction is rounded to the nearest whole number.

NOTE 2:

If a relative compaction value is less than specified by the contract, the Resident Engineer should be notified immediately. To date, some polymer concrete overlays have failed due to insufficient compaction of the material at the time of placement. Factors that cause inadequate compaction include:

- Insufficient resin in the polymer concrete mixture, insufficient quantities of catalysts and/or out-dated polymer materials.
- Insufficient or incomplete mixing (dry spots in the mix)
- Polymerization of the material prior to the compaction efforts
- The finishing machine moved too quickly to achieve adequate compaction
- Malfunctioning vibrators on the finishing machine

- Inadequate compaction effort attempted

F. REPORTING OF RESULTS

1. Record relative compaction values for each test area. (Do not average relative compaction values from two or more test areas).
2. Record the operator's name, the CHC number of the nuclear gage, date of test and time of test.
3. Sketch the location of each test area (record the km post or station and distance left or right of centerline).

G. PRECAUTIONS

When handling polymer concrete materials, use suitable protective clothing and eye protection. Respiratory equipment is required in poorly ventilated areas.

Polymer materials can be susceptible to burning prior to polymerization. Do not place these materials near an open flame or extreme heat.

Polymer resins and catalysts should always be mixed using guidelines and proportions recommended by the manufacturer.

H. SAFETY AND HEALTH

This method involves hazardous materials and extreme care must be used performing tests.


Prior to sampling, handling or testing, Caltrans personnel are required to read Sections 5.1, 5.2, 10.4, 12.1, 12.2 and 12.3 of the Laboratory Safety Manual. Requirements for general safety principles, standard operating procedures, protective apparel and how to handle spills, accidents and emergencies are discussed in the above-noted references.

Several types of polymer materials may be considered for overlay use. Testers are required to read the Materials Safety Data Sheets for the applicable polymer type specified. Prior to handling polymer materials in poorly ventilated areas, testers are required use appropriate respiratory equipment. Prior to the anticipated work, testers should be fitted for respiratory equipment according to the procedures outlined in Chapter 15 of Caltrans Safety Manual.


This method does not purport to address all the safety problems associated with its use. It is the responsibility of the user of this test method to consult and establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Users of this method do so at their own risk.

REFERENCE: California Test 231

End of Text (California Test 552 contains 4 pages)



PLAN VIEW
(Polymer Concrete Compaction Testing)



CROSS SECTION AT A-A

Note: More than one rigid test frame may be required for a project. A rigid test frame with a 50-mm height would be unacceptable for use on a project with a specified overlay thickness of 25 mm.

FIGURE 1 - RIGID TEST FRAME